PIFCO®



INSTRUCTION MANUAL

4" USB MINI DESK FAN

Please read before use and retain for future reference.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire electric shock, and injury to persons, including the following.

1. The fan is only for intended use as described in this manual. All other uses not recommended in manual may cause fire, electrical shock or injury to persons.
2. This fan is intended for household use only.
3. To protect against electrical shock, do not immerse fan or cord into water or spray with liquids.
4. Close supervision is necessary when any appliance is used by or near children.
5. Always unplug the fan when it is not in use, when moving fan from one location to another, and before cleaning.
6. Avoid contacting moving parts. Never insert fingers, pencils or other similar objects through the guard.
7. Do not operate in the presence of explosive or flammable fumes.
8. Do not place fan or parts near an open flame, cooking or other heating appliances.
9. Do not operate fan with a damaged cord or after the fan suffered malfunctions or has been dropped or damaged in any manner.

10. The use of attachment not recommended by manufacturer may be hazardous.
11. Do not use outdoors.
12. Ensure the cable is not a tripping or entanglement hazard.
13. Do not let cord hang over the edge of a table or counter, or let it touch any hot surfaces.
14. Always check for any debris in the USB port before inserting the charger cable.
15. Do not operate without fan lattice properly in place.
16. Always use on a dry level surface.
17. Children must be supervised by an adult if they are playing in the vicinity of the appliance.

OPERATION

1. Simply place the input of the USB charging cable into your power supply such as an adaptor or computer/other device.
2. Press the ON/OFF switch on reverse of fan.

CLEANING AND MAINTENANCE

Be sure to unplug from the electrical supply source before cleaning.

- **DUSTING:** Clean your fan periodically by lightly running a vacuum cleaner nozzle (soft brush) over the front and rear guards to remove any dust or dirt that may have accumulated inside or on the unit. Alternatively, use a soft, dry cloth for dusting.
- **STUBBORN STAINS:** Use a slightly damp, soapy cloth for stubborn stains but be sure the cloth is not too wet. Use caution around the motor housing. Do not allow the motor or other electrical components to be exposed to water.
- **END OF SEASON CLEANING:** When you have finished using the fan at the end of the season, wipe off any dust to maintain it in good working order for the next season.
- **STORAGE:** In the off season, store the clean and dry fan in a safe, dry location, protected from dust. We recommend using the original carton for storage. Alternatively, place a plastic bag or piece of material over the top of the cleaned fan for dust protection.
- **SERVICE/REPAIR:** The appliance requires no maintenance and contains no user-serviceable parts. Do not attempt to take the motor housing apart. Do not try to repair or modify the appliance. Do not operate the fan if its power cord or plug is damaged, or when it is working abnormally. In case of damage or malfunction, or if the cord is damaged, have the unit repaired by trained personnel only.

ENVIRONMENT FRIENDLY DISPOSAL

The symbol above and on the product means that the product is classed as Electrical or Electronic equipment and should not be disposed with other household or commercial waste at the end of its useful life. The Waste of Electrical and Electronic Equipment (WEEE) Directive(2012/19/EU) has been put in place to recycle products using best available recovery and recycling techniques to minimize the impact on the environment, treat any hazardous substances and avoid the increasing landfill. Contact local authorities for information on the correct disposal of Electrical or Electronic equipment.

CUSTOMER SUPPORT

For product support, go to webpage:
help.homebargains.co.uk

Dimensions:	155 X 80 X 150 (MM)
Power:	2.5W
USB input:	DC 5.0V 1.0A
USB cable included	

MADE IN CHINA

TJM Ltd, Liverpool L11 0JA
TJM Ltd, Belfast BT2 7FW

Images for illustration purposes only. Colour & contents may vary. Sizes are approximate.

Item code: 75989